



### SinoMeter VA18B with USB interface

This elegant digital multimeter features an optically isolated USB interface and Windows® software. The optical isolation ensures the digital multimeter is electrically isolated from the PC so that no damage can occur to the computer should there be a fault in the circuit under test. It also measures temperature, frequency, duty cycle, capacitance, AC+DC voltage and AC+DC current up to 10 Amps.

Code	Description
ME38VA18B	<b>USB DIGITAL MULTIMETER/ DATALOGGER</b> Auto/manual ranging 6000 count LCD (max reading 5999) USB interface to computer Relative measurement Data hold and LCD backlight Optically isolated USB interface Windows® Software Safety to IEC1010-1, CATII 1000V Data logging/Data acquisition The USB interface and software allows you to log and store measurements for later analysis. The software is Windows® XP and Vista compatible. Temperature probe, USB interface cable, Data acquisition software, high quality meter leads included